



8302341 | CREE LED Hood Light Conversion Kit for JD Tractors

Instruction Guide

1. Raise the hood to access nose cone and light bar
2. Disconnect wire harness (Connection is normally on RH of machine behind radiator)
3. Remove screws holding light in place and remove light bar from nose
4. Place new Hy-Cap light bezel into nose cone and secure with new screws.
(One screw on each end, center screw is no longer needed)
5. Install Hy-Cap lights into new bezel from the front, placing frames over lights and securing with new screws (provided)
6. Install new wire harness into light terminals, being sure to attach ground and hot wires to proper terminals
7. Attach the other end of the wire harness to OE connector and replace hood
8. Secure all hardware and wiring

Old OE Lights



New Hy-Cap Lights

