



HA232447 KIT [CREE LED Hi-Lo Beam Corner Headlight Kit, 9000 Lumens]

Instruction Guide

NOTE: Some models will have wiring for both Halogen and HID style lights. Be sure use the proper connector to power your Hy-Cap LED light. If replacing and HID light, also remove the ballast. The connector leading to the ballast may be used to power the Hy-Cap LED

1. Raise hood and remove the sliding clips that hold the light in place
2. Remove the light from the bezel
3. Disconnect wiring connectors
4. Connect wiring of new light to the connectors on the machine. (See note above)
5. Place new Hy-Cap light into bezel. (Your new Hy-Cap light has shoulder washers that will center the light in the bezel. Confirm that the washers have centered in the mount holes before proceeding
6. Install flat washers, lock washers and nuts and secure

