



HA232454 [CREE LED Flood/Spot Combo Center Nose Light, 9000 Lumens]

Instruction Guide

Hood Mounted Lights:

1. Raise hood and remove bolts in covering plate
2. Remove covering plate to gain access to rear of light
3. Remove bolts from light and disconnect wiring connector
4. Remove light from hood
5. Place new Hy-Cap LED light into bezel
6. Attach the wiring connectors

NOTE: Some models will have wiring for both Halogen and HID style lamps. The Hy-Cap light will require the connector that leads to the HID Ballast. The ballast can be removed from the machine, and the connector plugged directly into the Hy-Cap Light

7. Install washers and nuts to lamp and secure. Replace covering plate and bolts

Frame Mounted Lights:

1. Open front grille on machine and lower/release the catch plate on the underside of the machine
2. Remove 3 bolts that hold the lever and support in place and carefully move support to the side away from center light
3. Remove 4 bolts from rear of OE light
4. Remove bulb from OE light
5. Remove light from cavity in frame
6. Remove any foam that may remain in the cavity area

NOTE: Removal of excess foam is to allow new Hy-Cap LED light proper ventilation

7. Place new Hy-Cap light into cavity (some machines may have two separate mounting hole options. Your new Hy-Cap light mounting bolts should go through the upper holes)
8. Install washers and nuts to light and secure
9. Attach the wiring connectors

NOTE: Some models will have wiring for both Halogen and HID style lights. The Hy-Cap light will require the connector that leads to the HID Ballast. The ballast can be removed from the machine, and the connector plugged directly into the Hy-Cap light.

10. Replace lever support and bolts, and re-attach lever catch plate