

## HA87429393 KIT [CREE LED Hi-Lo Beam Corner Headlight Kit, 8000 Lumens]

Instruction Guide

Case IH Tractors: 180 Magnum, 190 Magnum, 200 Magnum, 210 Magnum, 215 Magnum, 220 Magnum, 225 Magnum, 235 Magnum, 240 Magnum, 245 Magnum, 250 Magnum, 255 Magnum, 260 Magnum, 275 Magnum, 280 Magnum, 290 Magnum, 305 Magnum, 310 Magnum, 315 Magnum, 335 Magnum, 340 Magnum, 370 Magnum, 380 Magnum, 380 Magnum, MX215, MX245, MX275, MX305

<u>Case IH Sprayers</u>: 2240 Patriot, 2250 Patriot, 3240 Patriot, 3340 Patriot, 4440 Patriot, 5550 Trident

<u>Steiger Tractors</u>:350, 370, 400, 420, 450, 470, 500, 540, 550, 580, 600, 620

- 1. Disconnect wiring connectors from the light
- 2. Remove (3) screws in plates that connect center and corner lights
- 3. Remove (4) mounting bolts that hold light in place, remove light
- 4. Install new light into grille and replace (4) mounting bolts (supplied)
- 5. Replace (3) screws into connecting plate (supplied)
- 6. Once light is positioned properly, secure lights by tightening all hardware
- 7. Attach blue electrical connector to power light
- 8. Repeat steps 1-7 for both lights

<u>Case IH Tractors</u>: 170 Puma, 170 Puma CVT, 170 Puma CVX, 180 Puma, 180 Puma CVT, 180 Puma CVX, 185 Puma, 185 Puma CVT, 185 Puma CVX, 195 Puma, 195 Puma CVT, 195 Puma CVX, 200 Puma, 200 Puma CVT, 200 Puma CVX, 210 Puma, 210 Puma CVT, 210 Puma CVX, 215 Puma, 215 Puma CVT, 215 Puma CVX, 220 Puma, 220 Puma CVT, 220 CVX, 225 Puma CVT, 225 Puma CVX, 230 Puma CVT, 230 Puma CVX, 240 Puma CVT, 240 Puma CVX

- 1. Disconnect wiring connectors from the light
- 2. To release the light, remove (3) screws from the plate that joins the lights together
- 3. Remove (4) mounting bolts that hold light in place, remove light from grille
- 4. Install new light into grille and replace (4) mounting bolts (supplied)
- 5. Replace (3) screws into connecting plate (supplied)
- 6. Once light is positioned properly, secure lights by tightening all hardware
- 7. Attach blue electrical connector to power lamp
- 8. Replace plastic panel
- 9. The original light contained a side light that will no longer be needed
  - The connection can be covered or sealed with electrical tape or wire nut
- 10. Repeat steps 1-7 for both lights