



# HA91974 KIT [CREE LED Hi-Lo Beam Corner Headlamp Kit for Case IH Magnum Tractors, 7800 Lumens]

## Instruction Guide

1. Each lamp is held in place by (3) bolts. Raise the hood of the machine & remove the nuts from each bolt
  - a. There are (2) bolts on the inner portion & (1) bolt on the outer portion of the lamp
2. Disconnect the electrical connector
3. Remove the lamp from the machine by sliding it forward out of the hood
4. Set new lamps into place while making sure to align the bolts & holes
5. Add nuts to secure lamps into place and attach electrical connector

