



HM4288656 [CREE LED Flood Beam Rear Cab Light, 1680 Lumens]

Instruction Guide

Wiring modifications may be needed for installation

1. Remove original light from bracket
2. Loosen bolts holding bracket to cab
3. By removing bracket, electrical connector is accessible inside of cab. Release this connector and remove light
4. Install new connector onto light & machine if needed
5. Replace bolts that secure bracket to cab
6. Install new light onto bracket. Be sure to install nylon spacers on either side of light before securing
7. Aim light to desired position and secure hardware

