



HR154906 [Bridgelux LED Wide Flood Beam Cab Rear Light, 3500 Lumens]

Instruction Guide

1. Disconnect electrical connector from original light
2. Remove original light and bracket from machine by removing the bolt through the cab
3. Align the new light and bracket on the original mounting hole and replace mounting bolt
4. Attach electrical connector
5. Adjust light beam to desired direction and secure all hardware

