



HR19077 [CREE LED Flood Beam Rear Cab Roof Light, 3200 Lumens]

Instruction Guide

1. Remove original light and bracket from the machine
2. Install new bracket (as seen in photo)
3. Attach light to bracket (as seen in photo)
4. Install electrical connector
5. Adjust to desired location and secure hardware. Lens may be turned if desired by removing 4 cap screws in rear of light

