



## HR19079 [CREE LED Flood Beam Rear Fender Light, 3200 Lumens]

Instruction Guide

1. Remove original light and bracket from the machine
2. Install new bracket onto machine
3. Install light onto bracket
4. Install electrical connector (If possible, place connection inside cab room)
5. Adjust to desired location and secure hardware

