



HR219708 [CREE LED Flood Beam Light, 1680 Lumens]

Instruction Guide

1. Remove OE light from machine leaving OE mount bracket intact
2. Using long bolt (provided), install links to light. Smaller link hole should be toward light, larger hole toward OE mount bracket
3. Attach links to OE mount by inserting short bolts inward. Install flange nuts
4. Install electrical connector
5. Adjust beam to desired direction and secure

