



HR35141 [CREE LED Flood Beam Light, 3200 Lumens]

Instruction Guide

1. Remove cover and lights from cab roof bracket
2. Retrain the nylon spacer used with original light
3. Using original spacer (tapered side down) position new light on top of spacer, install bolt, nut, and washers
4. Install electrical connector (included)
5. Aim beam to desired location and tighten
6. Replace cover

