



# HR58638 [CREE LED Hi-Lo Beam Forward Grille Light, 4200 Lumens]

## Instruction Guide

1. Insert bushings into bezel
2. Insert threaded screws in the corners of the light (which corners to insert them is determined by the light that is being replaced)
3. Place light into bezel from the front. Threaded screws in light should be inserted through the bushings
4. Secure with nylon wingnuts

