



# K3C581-75914 [CREE LED Flood Beam Cab Front & Rear Light, 3000 Lumens]

Instruction Guide

## Cab front work light

1. Remove original light from machine
2. Install electrical plugs onto light wires. (Red – Positive, Male Bullet, Black – Negative, Female Bullet)
3. Using the bracket that included the spacer, attach it to OE mount with the supplied 30 mm bolt/nut. Spacer portion of bracket should be positioned below original mount
4. Attach light to bracket using remaining nut
5. The flat bracket and 16 mm bolt will not be needed, they can be discarded

## Cab rear work light

1. Remove original light from machine
2. Install electrical plugs onto light wires (Red – Positive, Male Bullet, Black – Negative, Female Bullet)
3. Using the flat bracket without the spacer, attach bracket to OE mount using supplied 16mm bolt/nut
4. Attach light to bracket using remaining nut
5. The bracket with spacer and 30 mm bolt will not be needed, they can be discarded

