



KTD170-75300 [CREE LED Flood Beam Cab Front & Rear Light]

Instruction Guide

Cab Front Work Light

1. Remove original light from machine
2. Attach straight end of bracket onto light mount using hardware provided
3. Attach curved end of bracket to OE mount using hardware provided
4. Join electrical connectors, aim light to desired direction and secure hardware



Cab Rear Work Light

1. Remove original light from machine
2. Place new Hy-Cap light onto bracket, insert spacer and bolt through bracket
3. Attach silver light bracket directly onto OE mount using hardware provided
4. Join electrical connectors, aim light to desired direction and secure hardware

