



## HA301892 [Bridgelux LED Flood Beam Light, 3500 Lumens]

Instruction Guide

*This can be used as left or right-side light*

1. Remove original light from machine
2. Remove the U-shape bracket and plastic C-clip from original light
3. Install the U-shape bracket and plastic C-clip on the new Hy-Cap light
4. Insert wires from light through mount arm or into the cab post
5. Connect light wires to the wires on the machine
6. Attach light to machine by placing the U-shape bracket back into the mounted with the C-clip in place
7. Secure with OE nut (if necessary, use provided flat spacer with new bracket)
8. Adjust beam to desired direction & secure hardware

