



HAZAA7189850 [CREE LED Flood Beam Light, 3150 Lumens]

Instruction Guide

1. Remove original light and bracket from machine, disconnect electrical connector
2. Install new bracket using hardware provided
3. Insert electrical wiring through hollow bolt, install & connect electrical connectors
4. Install light onto bracket using hardware provided
5. Adjust beam to desired location & secure hardware

