



HF86038022 [Flood Beam LED Grille Light for Versatile Tractors, 4800 Lumens]

Instruction Guide

1. Remove the OE light from the bezel and disconnect the wiring harness
2. Remove the plastic ring from OE light
3. Using the OE screws and springs, install plastic the ring onto the new light
4. Attach the wiring harness onto the new light
5. Place the new light into the bezel and secure

