



HR52986 [LED Warning Light, Amber/Amber]

Instruction Guide

1. This light has 3 wires:
 - a. White – ground (with eyelet)
 - b. Black – Low power (for tail & turn)
 - c. Red – High power (for breaking, if wired)
2. If your machine only has one hot wire, it is likely the low power for tail and turn.
Remaining high power wire will not be needed

