

- 1. Remove screws holding light bracket to roof bezel
- 2. Remove OE light from bracket by removing the screws on each end
- 3. Disconnect old light connector, and connect new light to connector on machine
- 4. Place new light into bracket, attach with new hardware provided
- 5. Attach bracket onto roof bezel using original screws
- 6. Aim light to desired direction and secure hardware

